FLEXION FOOTBOX™ - DOUBLE





FLEXION FOOTBOX™ - DOUBLE

Parts Included:

Pre-Attached

- 2 (A) Screw 1/4-20 x 1/2" Button Head
- 2 (B) Washer 0.25" ID, 0.75" OD

From Kit Bag

- 1 (C) Allen Wrench 5/32
- 4 (D) Screw 1/4-20 x 1.25" Phillips Pan Head
- 4 (E) Screw 1/4-20 x 1" Phillips Pan Head
- 4 (F) Washer Internal Tooth, 5/16" ID
- 8 (G) Washer 0.25" ID, 1.25" OD
- 4 (H) Nut 1/4-20 Nylon Lock
- Remove center foam/cover piece.
- Place the Flexion Footbox on the wheelchair footplates in the required position.
- Drill 4 mounting holes through the bottom of the wheelchair footplates and through the bottom of the Flexion Footbox plate as shown in Figure 1. Holes must be big enough for a ¼"-20 screw.
- Attach the Flexion Footbox to the foot plates with screw (D or E) depending on the thickness of the foot plates; along with the washer (F), washers (G), and nut (H) using Allen Wrench (C) as shown in Figure 2.
- 5 Reattach the center foam/cover piece.
- Remove screw (A) and washer (B) on both sides using Allen Wrench (C) as shown in Figure 2.
- Adjust the angle of the Flexion Footbox to the required position as shown in Figure 3 and then reattach screw (A) and washer (B) to lock the Flexion Footbox in place.

FIGURE 1: MOUNTING HOLES




FIGURE 2: HARDWARE ATTACHMENT




FIGURE 3: ANGLE ADJUSTMENT

