



# EasyStand<sup>™</sup> Evolv<sup>™</sup>

## Perfect Fit Guide

*Proper positioning is needed to obtain optimum standing posture.*



### step one

Measure client for approximate seat depth (A) and footplate (B) settings.



### step two

To adjust seat depth, loosen the two ratchet handles under the seat (C). Depress the snap button on the adjustment tube while moving the back (D). Tighten the ratchet handles after adjusting.



### step three

After achieving your desired seat depth, rotate the back angle adjustment knob (E) so the increment indicator (F) is in the green (safe) area.



over ...




# EasyStand<sup>™</sup> Evolv<sup>™</sup>

## Perfect Fit Guide

*Proper positioning is needed to obtain optimum standing posture.*

### step four

Loosen the ratchet handles on the footplates to adjust height and plantar/dorsi (G). Client's knee should be slightly lower than the hip (H). Tighten ratchet handles after positioning.



### step five

Position the user's hips as close as possible to stander's hip pivot (I & J).



### step six

To determine correct positioning, you should be able to fit two fingers between the front of the seat and the calf (K). Adjust the kneepad so it fits comfortably up to the knees (L).



NOTE: There is no kneepad depth adjustment on the Glider.

For more information visit our website at [www.easystand.com](http://www.easystand.com) or call our customer service at 800•342•8968.